





Gcandy MINI

Revolutionary BIOSKIN material
As Close To The Human Skin



Press and hold for two seconds to switch on



Click to change the mode of vibration. The toy has 6 modes of vibration



Increase the vibration



Decrease the vibration /OFF

EN

Powerful motor for clitoris

Powerful motor for vagina

Press ⊕ and hold for two seconds to switch on.

⊕ increase the vibration

Ⓜ modes of vibration

⊖ decrease the vibration /OFF

DE

Leistungstarker Motor für die Klitoris

Leistungstarker Motor für die Vagina

Für die Entsicherung drücke ⊕ und halte den Knopf für zwei Sekunden lang gedrückt.

⊕ verstärken der Vibration

Ⓜ schwingungsarten

⊖ vibration verringern / OFF

FR

Moteur puissant pour le clitoris

Moteur puissant pour le vagin

Appuyez sur ⊕ et maintenez la touche enfoncée pendant deux secondes.

⊕ augmentation de la force de vibration

Ⓜ modes de vibration

⊖ réduction de la force de vibration / OFF

ES

Potente motor para el clítoris

Potente motor para vagina

Pulse ⊕ y mantenga pulsado durante 2 segundos.

⊕ aumentar la intensidad de la vibración

Ⓜ modos de vibración

⊖ reducir la intensidad de la vibración / OFF

RU

Один сильный мотор для клитора

Сильный мотор для вагины

Нажмите ⊕ и удерживайте 2 секунды для включения.

⊕ увеличение силы вибрации

Ⓜ режимы вибрации

⊖ уменьшение силы вибрации /OFF

3-YEAR WARRANTY